



10.1866.1 Scan-Tech Tailgate Repair Kit

Fits: Volvo 700 / 850/ 900 Wagon
V90
V70 ~ 2000
V70XC ~ 2000



OE Reference Number: 9451866

Contains: 4 metal plates, 12 self drilling screws, 4 Clips 10.2876 (OE Reference 9132876) and 4 Clips 10.5885 (OE Reference 9145885)

Installation Procedure:

- Open tailgate to the fully raised position.
- Carefully pry the handle trim loose.



- Remove the tailgate panel per the shop manual procedure.
- Inspect plastic standoffs for damage.



- Place metal repair bracket over the damaged standoffs, bend down flaps, and secure in place with self drilling screws provided.





- Replace all plastic clips (top and bottom) with clips provided; based on the model you may have some clips left over.



Bottom



Top

- Reinstall the tailgate panel and the handle trim panels making sure to both are properly seated.



- Refer to the shop manual for additional information if required.

WWW.ScanTechSweden.Com